


DUOJET AIR CURTAIN

Open the service door to access inside the air curtain:



ELECTRICAL HEATING CONNECTION

Duojet Electrical
Terminal Block




FANS CONNECTION

Duojet Fans
Connection Boxes



1 connection for each fan group (Max 6 fans for group)

- ① **M20** - Electrical Heating Klixon (Min 1mm²)
- ② **M25** - Electrical Heating Power
19,20,21 (Min 2,5mm²) / 22,23,24 (Min 4mm²)
- ③ **M20** - Fans Group 1 (Min 2,5mm²)
- ④ **M20** - Fans Group 2 (Min 2,5mm²)
(* only for models 2500 and 3000)



TRIOJET BOX

CLEVER
PCB

DUOJET 7 ... 24

EXTERNAL
TEMPERATURE
SENSOR
(5,6)



DOOR
CONTACT N.O.
(3,4)





RJ11

POWER SUPPLY (400V ~ 3 50Hz) (Min 10mm²)

KOOL (1,2,L,N,⊕)



CLEVER
CONTROL TFT
BOX



KOOL AIR CURTAIN
EC FANS